

COMPACT FILTRATION CHECKLIST

Store name	<input type="text"/>	Store No.	<input type="text"/>	Week Commencing	Day <input type="text"/>	Month <input type="text"/>
Sock change due:	<input type="text"/>	Central bag change due:	<input type="text"/>			

Daily Checks

Empty excess waste water into central filter unit and the solid debris into appropriate waste bin, checking socks throughout the day that they are water tight. Please wear Safety glasses and the gloves provided when using the wrench.

TO BE COMPLETED AND SIGNED BY TEAM MEMBER

	Mon	Tues	Wed	Thurs	Fri	Sat	Sun
1 FILTRATION SOCKS EMPTIED AND CONDITION OF SOCKS CHECKED							
2 FILTRATION SOCKS COLLAR TIGHTENED CORRECTLY AND TESTED FOR ANY LEAKS							
3 MAIN TANK WATER CHECKED AND FILLED TO CORRECT LEVEL							
4 CHECK WATER FLOW IN EDGING CHAMBER							
	Mon						Mon
5 WATER TEMP MID PRODUCTION READING		6 ROOM TEMP MID PRODUCTION READING					

Filtration Sock replacement and Conditioner Replenishment

We recommend that the socks are changed at around 3000 lenses (this may differ due to water quality and lens material) and that conditioner is added at every sock change and also at the half way point of the socks life (1500 lenses). Please wear safety glasses and the gloves provided when using the wrench.

1	To replace the filtration socks and replenish conditioner supplied by Mainline Optical please follow the instructions given on the day of installation or revert to the user manual.
2	Check the condition of all the collars and 'o' rings to make sure there is no damage
3	Refer back to step 2 in daily checks
4	Add in 1 litre of conditioner to tank when replacing socks

Central chamber bag replacement

We recommend that the central chamber bag is replaced every 6 months or when required. We also recommend at this point that you empty and clean out your tank using the cleaning kit provided. See Manual.

1	Order a replacement bag from Mainline Optical
2	Add in 1 litre of conditioner when refilling tank with fresh water

REPLACEMENT CENTRAL CHAMBER BAG CODE: GDF01 • REPLACEMENT SOCK CODE: COMP/CH

Weekly checks complete

Name:	<input type="text"/>	Signature:	<input type="text"/>
-------	----------------------	------------	----------------------